

Measurement example



Functions

Zero-setting
Origin restoration
Data hold
Function lock
Automatic power ON/OFF
2-point Preset
Error alarm
Data output

Optional Accessories

Code No.	Type	description
264-020	—	USB Input Tool Series USB Keyboard Signal Conversion Type IT-020U
05CZA662	B	Connection cable (1 m)
05CZA663	B	Connection cable (2 m)
06AFM380B	B	USB Input Tool Direct (2 m)
02AZD730*	IP67	U-WAVE-T
02AZD880*	Buzzer	U-WAVE-T
02AZD790B	B	Connection cable for U-WAVE-T (160 mm)
02AZE140B	B	Connection cable for U-WAVE-T For foot switch

* Add suffix to Code No.; **G** for Asia, Europe and the Americas,
H for Brazil and **J** for Korea.

Tubular Inside Micrometers SERIES 339 — Extension-pipe Type

- Wide range of inside measurements possible by combining Extension pipes and anvils with the micrometer head.
- Carbide-tipped measuring faces.
- IP65 (water-proof) protection level that enables use in the presence of cutting fluid.
- A reference gage is necessary for reference point setting.



339-301

SPECIFICATIONS

Metric							
Code No.	Range (mm)	Resolution (mm)	Spindle feed error* (μm)	Micrometer head stroke (mm)	Qty	Extension pipes Size (mm)	Display unit (mm)
339-101	200 - 225	0.001	3	25	—	—	200 - 225
339-301	200 - 1000				5	25, 50, 100, 200, 400	
339-302	200 - 2000				8	25, 50, 100, 200 (2 pcs.), 400 (3 pcs.)	

Inch/Metric							
Code No.	Range (in)	Resolution	Spindle feed error* (in)	Micrometer head stroke (in)	Qty	Extension pipes Size (in)	Display unit (in)
339-102	8 - 9	0.0001 in/ 0.001 mm	0.00015	1	—	—	8 - 9
339-303	8 - 40				5	1, 2, 4, 8, 16	
339-304	8 - 80				8	1, 2, 4, 8 (2 pcs.), 16 (3 pcs.)	

- Power source: SR44 battery (1 pc.), **938882** included as standard (for operational checks)
- Battery life: Approx. 1.2 years under normal use
- Position detection method: Electromagnetic induction-type rotary encoder
- * "Spindle feed error" refers to the difference between the maximum and minimum indication error values within the measuring range of the micrometer head