



## ABSOLUTE Digimatic Indicator ID-U SERIES 575 — Slim and Economical Design

- Cost-effective and user-friendly type with basic functions.
- Battery life: approx. 20,000 hours in continuous use.
- The ABS (ABSOLUTE) scale restores the last origin position\* automatically when the indicator is turned on, and realizes high reliability by eliminating over-speed errors.
- Equipped with a data output port that enables incorporation into measurement networking and statistical process control systems. (Refer to page 09-3)

\* Refer to "Precautions for use" on page 07-2.



575-121

### SPECIFICATIONS

Metric		ISO/JIS Type					
Code No.	Range (mm)	Resolution (mm)	Maximum permissible error (MPE)* <sup>1</sup> (mm)				Maximum permissible limit (MPL)
			Partial measuring range $P_{MPE}$	Total measuring range $E_{MPE}$	Hysteresis $H_{MPE}$	Repeatability $R_{MPE}$	
575-121	25.4	0.01	0.02	0.02	0.02	0.01	1.8 or less

Inch / Metric		ISO/JIS Type					
Code No.	Range	Resolution	Maximum permissible error (MPE)* <sup>1</sup> (mm)				Maximum permissible limit (MPL)
			Partial measuring range $P_{MPE}$	Total measuring range $E_{MPE}$	Hysteresis $H_{MPE}$	Repeatability $R_{MPE}$	
575-122	1 in / 25.4 mm	0.0005 in / 0.01 mm	0.02	0.02	0.02	0.01	1.8 or less

Inch / Metric		ASME/ANSI /AGD type				
Code No.	Range	Resolution	Maximum permissible error (MPE)* <sup>1</sup> (in)			Maximum permissible limit (MPL)
			Overall* <sup>2</sup>	Hysteresis	Repeatability	
575-123	1 in / 25.4 mm	0.0005 in / 0.01 mm	±0.0010	0.0010	0.0005	1.8 or less

- Display: 5-digit display, sign
- Power source: SR44 battery (1 pc.), **938882** included as standard (for operational checks)
- Battery life: Approx. 20,000 hours of continuous use. Approx. 5 years under normal use.

Note: It varies depending on use frequency and method. Please take the values as rough indications.

- Lifting lever: **21EAA426** (standard accessory)

\*1 These values apply to normal measurements at 20 °C.

\*2 Overall magnification and linearity

### Function

- Origin set (Zero-setting)
- Measuring direction switching
- Data output
- Low battery voltage alarm display
- Error alarm display

### Optional Accessories

Code No.	Type	Description
264-020	—	USB Input Tool Series USB Keyboard Signal Conversion Type <b>IT-020U</b>
905338	F	Connection cable (1 m)
905409	F	Connection cable (2 m)
06AFM380F	F	USB Input Tool Direct* (2 m)
02AZD730G	IP67	<b>U-WAVE-T</b>
02AZD880G	Buzzer	<b>U-WAVE-T</b>
02AZD790F	F	Connection cable for <b>U-WAVE-T</b> (160 mm)
02AZE140F	F	Connection cable for <b>U-WAVE-T</b> For foot switch
02AZD810D	—	<b>U-WAVE-R</b>
02AZE200	—	<b>U-WAVE-T</b> mounting bracket

\* Please separately purchase **USB-ITPAK** since there is no data output switch on the measurement instrument. (Refer to pages 09-15 to 09-17 for details.)

- Spindle lifting cable (stroke: 10 mm): **21JZA295**
- With auto-stop function:  
**21JZA301** (overall length 300 mm)
- Contact points for Mitutoyo Digimatic indicators (optional)  
Refer to pages 07-63 to 07-68 for details.
- Measuring stands (optional)  
Refer to pages 07-97 to 07-103 for details.